









INSTRUKCJA OBSŁUGI

Blokada uniwersalna (Ex) miniaturowego wyłącznika instalacyjnego

S2394



Master Lock.



www.masterlocksafety.com • www.masterlock.com

© 2013 Master Lock Company LLC | All Rights Reserved
Master Lock Company LLC, Milwaukee, WI 53210 U.S.A. | 800-308-9244
Master Lock Canada, Oakville, Ontario L6H 5S7 Canada | 800-227-9599
Master Lock Europe S.A.S; 0033.1.41.43.72.00; E-mail: safety@master-lock.fr
Master Lock Europe-UK Office, Wakes Colne, Colchester CO6 2DB, UK, 0044.1.787.222.027, E-mail: safetyeu@mlock.com
玛斯特锁贸易(上海)有限公司 上海市浦东新区银城中路168号上海银行大厦1006室 400-820-6535 E-mail: safetychina@mlock.com

P26543



ul. Marecka 66a
05-220 Zielonka
www.topserw.pl
info@topserw.pl
INFOLINIA: 801 000 501